

# CANZAC<sup>®</sup>

## SINAK S-102

### INSTALLATION INSTRUCTIONS

#### **General Application Instructions:**

The application should begin as soon as the surface can support foot traffic without leaving marks; and should be a continuous process from start to finish of the project. The application should not be interrupted except for rain.

1. Remove all debris that may prevent penetration of the S-102™.
2. Apply S-102™ in 2 light, even coats with a garden or airless sprayer.  
**DO NOT** apply S-102™ in heavy coats.
3. Immediately after the first coat is dry, apply a second coat.  
**NOTE:** “Dry” means dry to touch and the concrete had returned to original colour. Drying time will vary from 10 – 30 minutes depending on temperature/environment.
4. Clean all equipment by rinsing with water.

#### **Early Cure:**

S-102™ may be used for early cure/evaporation control and finishing aide when applied immediately after concrete placement.

1. Apply as much S-102™ as required to obtain desired results. After finishing the concrete, apply a second coat of S-102™.
2. Clean all equipment by rinsing with water.

**IMPORTANT:** The treated area is immediately available for foot traffic after the water spray application is dry to the touch.

#### **Vertical Applications:**

For vertical applications a maximum 9.5mm nap roller may be used. Product rundown should be anticipated. Use a dry 9.5mm nap roller to pick any and all rundown. Should the roller become saturated, change to a new, dry roller. Roller application may be used for both the first and second coat. Allow the first coat to dry to the touch and return back to original colour before applying the second coat. Excess material not picked up by the roller may result in white scaly residue. After the second coat has dried, wet the entire area with a light water spray.

### ***Hot Weather Application:***

In hot, dry, and/or windy conditions apply S-102™ shortly after loss (evaporation) of surface water or upon completion of Soft-Cut operation. Follow the General Application Instructions.

### ***Cold Weather Application:***

In freezing temperatures, or if freezing is possible, call CANZAC for technical advice. The water coat used after the S-102™ curing application is not required. The water merely removes any excess material and is typically only used on vertical smooth surfaces. The water coat does not have any effect on the finished installation.

After application of S-102™ no other curing method is required.

### ***Coverage Rates:***

Approximately 12 – 17 sq. metres per litre (subject to surface finish).

### ***Storage & Handling:***

Store in a cool dry area out of direct sunlight. Must be kept in tightly secured containers to prevent evaporation and contamination.

S-102™ MUST be protected from freezing. Product that has frozen will not function as intended, and should be discarded.

**FOR ANY QUESTIONS PLEASE CONTACT CANZAC® ON  
0800 422 692 or 03 343-4254**

### ***Limited Warranty***

Sinak Corporation warrants its products to be of the highest quality. Since application of the product is a crucial factor in obtaining satisfactory results, and is beyond the control of Sinak Corporation, refund of purchase price or replacement of product shall constitute the limit of Sinak Corporation's liability. Sinak Corporation makes no other warranties, express or implied, with respect to the products or any service and disclaims all other warranties, including any warranty of merchantability and fitness for a particular purpose. This limited warranty may not be modified by representatives of Sinak Corporation, its distributors or dealers.

**CANZAC®**

PO Box 3181, Christchurch Mail Centre, 8140, 3 Parkhouse Road, Wigram, Christchurch, 8042

Phone: 03 343-4254 • Fax: 03 343-4237 • Email: [info@canza.com](mailto:info@canza.com) • [www.canzac.com](http://www.canzac.com)

**Under Slab – In Slab – On Slab®**